




FOOS PILOT

Smart Control. Better Training. Stronger Bond.

INSTRUCTIONAL GUIDE

BEFORE YOU START

Check all components before use.




IMPORTANT:

- For best results, attach the leash to your dog's harness whenever possible.
- Avoid attaching the leash directly to the receiver collar.
- Make sure the collar is fitted securely but comfortably.
- Check the receiver and remote before beginning training.
- Keep the receiver clean and dry during use.


NOISE + VIBRATION

REMOTE CONTROL OVERVIEW

Remote Control Functions



DISPLAY INDICATORS



RESPONSE ICONS



HOW TO USE

Correct Leash & Collar Connection



Do not attach the leash directly to the receiver collar.

Direct leash pressure may place unnecessary strain on your dog's neck.



Attach the leash to your dog's harness whenever possible.

If a harness is not available, use a suitable collar strap with a D-ring and connect the leash to the D-ring.

POWER ON & MODES

Power ON / OFF

Press the ON/OFF button firmly to power the remote ON or OFF.



Short beep + red light:
Remote is ON

Long beep:
Remote is OFF

SWITCHING BETWEEN MODES

With the remote powered ON, press the ON/OFF button to toggle between: **AUTOMATIC MODE** and **MANUAL MODE**

AUTOMATIC MODE

When Automatic Mode is selected, the receiver is activated automatically when the dog pulls or yanks the leash.

There are 3 response levels, directly proportional to the intensity of the pull:

LEVEL 1	LEVEL 2	LEVEL 3
NOISE ONLY	NOISE + VIBRATION	NOISE + VIBRATION + STATIC SHOCK

RESPONSE INDICATORS

The flashing icons indicate which response has been triggered (in both manual and automatic modes).

Noise Feedback

Vibration Feedback

Static Shock Feedback

AUTOMATIC MODE NOTES

- Manually activating the receiver will not switch the device out of Automatic Mode.
- After 30 minutes of inactivity, the remote will automatically switch to Manual Mode to conserve battery life.
- If Manual Mode is selected, Automatic Mode will NOT function.
- In Manual Mode, there will be no automatic response when the dog pulls the leash.

MANUAL MODE

In Manual Mode, Use the + / - buttons to increase or decrease the intensity of the noise or static shock response.

Noise response: The intensity does not change.

Response Indicators



WHAT'S INCLUDED

Everything you need for setup and training.



Anti-Tugging Collar Receiver



Remote Control



Nylon Rope Style Leash

What's Included in the Box



Leash



Anti-Tugging Collar Receiver



Control Handle



2x Collars



Multiple Probes



Rubber Probe Covers



Static Shock Tester



Dual Charging Cord